Merlin+ (Professional Series) Remote Coding Instructions

Programming the transmitter into your motor (MT Series):

1. Press and hold the selected remote push button (on your new remote) that you wish to open the door
2. Press and release the orange “learn” button on the opener panel. The opener light will flash once. Release the remote push button. If no light bulb is installed, 2 clicks will be heard.

Programming the transmitter into your motor (MR Series):

1. Press and hold the selected remote push button (on your new remote) that you wish to open the door. The orange LED will flash.
2. Press and release the purple “learn” button on the opener panel. The opener light will flash once. Release the remote push button. Release the remote push button.

Note: if you release the remote push button before the opener light or LEDs flash, the opener has not accepted the code

To delete all of the transmitters that has been coded into the motor:

Press and hold the "Learn" button on the opener panel until the indicator light turns off (about 6-10 seconds).

Please note that the remote only has 3 working buttons. That is why you will notice that when you press the one button, the LED does not come on.